

General requirements:

Number of pipe penetrations per cabinet	2
max. cut-out cross-section per cabinet	1412mm ²
max. pipe diameter (d)	28mm
max. hose diameter (d)	28mm
max. cable diameter (3x 1,5 ²) (d)	8mm
Pipe material	steel /stainless steel
max. pipe wall thickness	1mm
max. hose wall thickness	3mm

Note!

A: Pipes and cables are installed in holes with their nominal diameters (d).

B: Hoses < Ø20mm are installed in holes with their nominal diameters (d).

C: Hoses ≥ Ø20mm are wound continuously completely with a layer of intumescent strip (see Fig. 2). Drillhole diameter= nominal diameter (d) + 3,6mm.

D: Drillholes can be designed to the upper tolerance of the nominal diameter (d) or at most be rounded up to the next full millimetre. Gaps between the pipe/ hose/ cable and the insulation must be avoided.

E: Unused drillholes must be closed properly!

F: The minimum distance between the holes must be 15mm (see Fig.3).

The pipe penetration may only be attached in the marked attachment areas

(see page 2-6) for the respective cabinet type! The edge of the frame defines the outer limit of the attachment area.

The drillhole must always be perpendicular to the attachment area.

The door locking must not have any negative effects, when attaching the pipe penetration!




The ventilation shafts (areas above and under the ventilation connections) must not be damaged, when attaching the pipe penetration on the rear panel.

The pipes/ hoses/ cables to be fed in must not block the doors!

The pipes/ hoses/ cables to be fed in must not block the inside valve flaps!

The pipe penetration is assembled in the following order in preparation for the attachment: 1. Intumescent material, 2. Insulation, 3. Frame (see Fig. 1)

Use Ø3,5 x 9,5 screws for fixing onto the sides or top and Ø4,5 x 50 screws for fixing onto the rear panel.



Model type	
S, S-5	page 2
M, M-5	page 3
L, L-5	page 4
LD, LD-5	page 5
XL, XL-5	page 6

Cross-section calculation:

$$A = \text{Cross-section area} = 3,14/4 \times d^2 \approx 0,785 \times d^2$$

Example for assignment:

1x Ø20mm + 2x Ø15mm:

$$A = 1 \times 0,785 \times 20\text{mm}^2 + 2 \times 0,785 \times 15\text{mm}^2$$

$$A = 667,25\text{mm}^2$$


The drawing is our property and may not be copied or made accessible to third parties without our written permission.

DÜPERTHAL Sicherheitstechnik
Frankenstraße 3
D-63791 Karlstein

title: Installation instruction pipe penetration
UTS standard / pro


part number: 55214 drawing number: 000041135

revision: 05 date: 2024-04-18 page: 1 von 6




DÜPERTHAL

Side left / right



Top panel



Description for:

- Classical door technology (door handle) and Push-to-open
- Cabinet depth 600 and 500

 Attachment areas

Model type: S, S-5

The drawing is our property and may not be copied or made accessible to third parties without our written permission.


title: Installation instruction pipe penetration
UTS standard / pro

part number: 55214 drawing number: 000041135


revision: 05 date: 2024-04-18 page: 2 von 6

DÜPERTHAL Sicherheitstechnik
Frankenstraße 3
D-63791 Karlstein


 **DÜPERTHAL**




Side left / right



Rear panel



Top panel



29-10000-x48
120 x 120

Description for:

- Classical door technology (door handle) and Push-to-open
- Cabinet depth 600 and 500

 Attachment areas

Model type: M, M-5

The drawing is our property and may not be copied or made accessible to third parties without our written permission.


title: Installation instruction pipe penetration
UTS standard / pro

part number: 55214 drawing number: 000041135


revision: 05 date: 2024-04-18 page: 3 von 6

DÜPERTHAL Sicherheitstechnik
Frankenstraße 3
D-63791 Karlstein


 **DÜPERTHAL**




Side left / right




Rear panel for model type L, L-5 standard and L pro



Top panel



Rear panel for model type L-5 pro



 Attachment areas

Model type: L, L-5

Description for:
 - Classical door technology (door handle) and Push-to-open
 - Cabinet depth 600 and 500

The drawing is our property and may not be copied or made accessible to third parties without our written permission.


title: Installation instruction pipe penetration
 UTS standard / pro

part number: 55214 drawing number: 000041135


revision: 05 date: 2024-04-18 page: 4 von 6

DÜPERTHAL Sicherheitstechnik
 Frankenstraße 3
 D-63791 Karlstein







Side left / right



Rear panel



Top panel



Description for:

- Classical door technology (door handle) and Push-to-open
- Cabinet depth 600 and 500

 Attachment areas

Model type: LD, LD-5

The drawing is our property and may not be copied or made accessible to third parties without our written permission.





title: Installation instruction pipe penetration
UTS standard / pro

part number: 55214 drawing number: 000041135

revision: 05 date: 2024-04-18 page: 5 von 6

DÜPERTHAL Sicherheitstechnik
Frankenstraße 3
D-63791 Karlstein

 **DÜPERTHAL**



Description for:
 - Classical door technology (door handle) and Push-to-open
 - Cabinet depth 600 and 500

 Attachment areas

Model type: XL, XL-5

The drawing is our property and may not be copied or made accessible to third parties without our written permission.	title: Installation instruction pipe penetration UTS standard / pro		
	part number: 55214	drawing number: 000041135	
DÜPERTHAL Sicherheitstechnik Frankenstraße 3 D-63791 Karlstein	revision: 05	date: 2024-04-18	page: 6 von 6
			